

Tapout Tuning Carbon Fiber Engine Cover Installation Instructions

MKD 5/2/2022



Tools Required:

- T30 torx bit

Installation:

1. Remove your existing engine cover by using a T30 torx bit, and unscrewing the oil fill cap. It's a good idea to reinstall the oil fill cap until you're ready to install your new carbon fiber engine cover to avoid any possible contaminants entering your engine.
2. Transfer all rubber components from your existing plastic engine cover. This includes:
 - Two pieces on the back of the cover that clip on to the mounts, shown in Picture 1.



Picture 1

- The rubber seal that goes under the oil fill cap, shown in Picture 2.



Picture 2

- Two rubber cones towards the front of the engine cover on the bottom side, shown in Picture 3.



Picture 3

- The round rubber grommet and metal sleeve that the T30 screw passes through, shown in picture 4.



Picture 4

3. Once those have been transferred over, remove the oil fill cap and install the carbon fiber engine cover just as you would the OEM plastic unit.
4. Reinstall and tighten T30 screw and reinstall oil fill cap.
5. Enjoy that glorious carbon fiber.